UEFI 설정 TOOL : cctk.exe Version 2.2.1 (mxml1.dll 필요)

Section 1. 관리자 패스워드 변경하기

※ 모든 명령은 관리자 커맨드를 이용하여 작업한다.

Usage: cctk --option[=argument]

For more information about a particular command,
use the option '-h' followed by the command name.

Example: cctk -h --asset

--acpower	--iptt	--speedstep
--admsetuplockout	--irsttimer	--strongpwd
--advbatterychargecfg	--lastbiosupdate*	--svctag*
advsm	--legacyorom	--sysdefaults
--asset	-l or --logfile	--sysid*
--autoon	--mediacard	--sysname*
--autoonhr	--mem*	--syspwd
--autoonmn	--mfgdate*	--sysrev*
--bioscharacteristics*	--microphone	--tpm
--bioscurrentlang*	--minsizeofcontigmem*	--tpmactivation
--bioslistinstalllang*	--multicpuore	--tpmppidpo
--biosromsize*	--multidisplay	--tpmppipo
--biosver*	-n or --namefile	--trustexecution
--blocks3	--numlock	--turbomode
--bluetoothdevice	--oromkeyboardaccess	--uefinwstack
bootorder	-o or --outfile	--usbemu
--chasintrusion	--ovrwr*	--usbport00
--chassisintrustatus	--passwordbypass	--usbport01
--clearsel	--pci*	--usbport02
--completioncode*	--peakshiftbatterythreshold	--usbport03
--cpuore	--peakshiftcfg	--usbport04
--cpucount*	--postmebxkey	--usbport05
--cpuspeed*	--propowntag	--usbport06
--cstatesctrl	--pwdlock	--usbportsfront
--deepsleepctrl	--rptkeyerr	--usbpowershare
--embnic1	--sata0	--usbwake
--embsataraid	--sata2	--uid*
--fanctrllovr	--sata4	--valsetuppwd
--fastboot	--secureboot	--valsypwd
--firstpowerondate*	--serial1	--version*
--forcepxeonnextboot	--serrdmimg	--virtualization
--hddinfo*	--setuppwd	--vtfordirectio
--hddpwd	--sfuenabled	--wakeonlan
-h or --help	--smarterrors	--watchdogtimer
-i or --infile	--speaker	--wirelesslan
--integratedaudio	--speakervol	

1. 관리자 패스워드가 없는 경우 암호 설정하기

```
C:\> 관리자: C:\WINDOWS\system32\cmd.exe  
C:\Wdell>cctk --setuppwd=newpassword --logfile=c:\Wdell\cctk.log  
Password is set successfully.
```

C:\Wdell>cctk --setuppwd=newpassword --logfile=c:\Wdell\cctk.log

//로그

2024/12/18 18:26:50 cctk -

Password is set successfully.

2. 관리자 패스워드 변경하기

```
C:\> 관리자: C:\WINDOWS\system32\cmd.exe  
C:\Wdell>cctk --setuppwd=thepassword --valsetuppwd=newpassword --logfile=c:\Wdell\cctk.log  
Password is changed successfully.
```

C:\Wdell>cctk --setuppwd=thepassword --valsetuppwd=newpassword --logfile=c:\Wdell\cctk.log

//로그

2024/12/18 18:30:56 cctk -

Password is changed successfully.

3. 관리자 패스워드 제거하기

```
C:\> 관리자: C:\WINDOWS\system32\cmd.exe  
C:\Wdell>cctk --setuppwd= --valsetuppwd=thepassword --logfile=c:\Wdell\cctk.log  
Password is cleared successfully.
```

C:\Wdell>cctk --setuppwd= --valsetuppwd=thepassword --logfile=c:\Wdell\cctk.log

//로그

2024/12/18 18:33:22 cctk -

Password is cleared successfully.

Section 2. Legacy boot 설정 변경하기

1. USB 부팅시도시 Legacy Boot 암호요구가 없으므로 Legacy Boot 메뉴 사용안함 변경

```
C:\> 관리자: C:\WINDOWS\system32\cmd.exe  
C:\> c:\dell>cctk --legacyorom=disable --valsetuppwd=setpassword --logfile=c:\dell\cctk.log  
legacyorom=disable
```

//로그

2024/12/18 18:53:24 cctk - legacyorom=disable

2. 세부 기능은 Dell CCTL(GUI) 버전이 제공되므로 참고.

끝.